SERVICE BULLETIN



www.apevibro.com

VIBRATORY HAMMERS • POWER UNITS AUGER SYSTEMS • DIESEL & HYDRAULIC HAMMERS

DRILL RIGS • HYDRAULIC PILING RIGS • WICK DRAIN INSTALLERS • LEAD SYSTEMS

Sep. 25, 2015



www.jandm-usa.com


#23 How To Air Bleed A Black Bruin Drill Motor



Black Bruin product bulletin

Air bleeding procedure for SD motor, vertical mounting

When air bleeding a vertically mounted SD motor (output shaft down), it is important to bleed the air out by opening one of the bleed screws in the rear cover (see below). If the screws aren't completely even, use the topmost screw. Due to motor's construction, failure to bleed through one of these screws will leave an air pocket into motor's housing cavity and can cause a catastrophic failure.



Air bleeding procedure (Operating Manual 2014-12-05)

Air bleeding procedure is carried out to fill the housing of the motor completely with hydraulic fluid. Air is removed from the housing with air bleeding screws as follows:

Connect the port C2 to a drain line and feed hydraulic fluid into the motor via port C1 throughout the air bleeding procedure.

- Locate the topmost air bleed screw of the housing.
- Unscrew the air bleeding screw by half a turn and let air escape from the housing.
- Close the screw when only hydraulic fluid is pouring through it.
- Tighten the screw to a torque of 39 ± 3 Nm.

Black Bruin No power like it.

Black Bruin by Sampo Hydraulics www.blackbruin.com

APE HEADQUARTERS

7032 S 196th Street Kent, WA 98032 (800) 248-8498 • (253) 872-0141 FAX (253) 872-8710

NORTHEAST REGIONAL OFFICE

401 Hartle St.
Sayreville, NJ 08872
(888) 217-7524 • (732) 432-6604
Fax (732) 432-6608

APE CHINA

Building No. 233, Fu Qiao Road Gu Cun Industrial Zone Baoshan District Shanghai, China 201906 011-86-21-5677-1221 Fax 011-86-21-3604-0553

LOUISIANA REGIONAL OFFICE

39266 A Doyle Drive Gonzales, LA 70737 (225) 644-7722 Fax (225) 644-7626

GULF REGIONAL OFFICE

3975 FM Hwy 1485 CONROE, TX 77306 (800) 596-2877 • (936) 271-1044 Fax (936) 271-1046

MID-ATLANTIC REGIONAL OFFICE 500 NEWTON ROAD, #200

500 Newton Road, #200 Virginia Beach, VA 23462 (866) 399-7500 • (757) 518-9740 Fax (757) 518-9741

SOUTHEAST REGIONAL OFFICE 1345 INDUSTRIAL PARK ROAD MULBERRY, FL 33860 (800) 570-3844 · (863) 324-0378 FAX (863) 318-9409

MID-WESTERN REGIONAL OFFICE 50 GERBER INDUSTRIAL DR. ST. PETERS, MO 63376 (877) 296-8044 • (636) 397-8400 FAX (636) 278-4278

WESTERN REGIONAL OFFICE 2985 LOOMIS ROAD STRONGER CA 05205

2985 LOOMIS ROAD STOCKTON, CA 95205 (888) 245-4401 • (209) 942-2166 FAX (209) 942-2455